


BMW M2 G87 Carbon Fiber Spoiler Wing Assembly Instruction

- 1. Place a few pieces of protective tape on the furthest ends of the trunk lid.
- 2. Place the trunk lid mount on the tape and mark the holes.
- 3. Drill through the trunk lid as marked. Use a 6 mm drill bit.
- 4. From the inner side of the trunk lid widen the drilled holes, but only the ones located closer to the center of the lid. Use a 19 mm wide hole saw. Drill out two of the three sheet metal layers with a hole saw.



























- 5. Place the gasket to match the holes and place the trunk lid mount over it.
- 6. Secure the trunk lid mount to the trunk lid with tape.
- 7. Prepare the mounting screws and washers. Apply a low-tear locking adhesive to the thread.
- 8. Screw the trunk lid mount, with the gasket in place, to the trunk lid.
- 9. To attach the external screws, cut the nuts appropriately to fit the trunk lid reinforcements.











+48 14 307 06 04 sales@maxtondesign.eu



10. Attach the mounting brackets to the spoiler. Apply a low-tear locking adhesive to the mounting screws thread.

- 11. Screw the mounting brackets to the mounts on the spoiler.
- 12. Put the plugs into the holes in the trunk lid.
- 13. Place the spoiler mounting brackets with the trunk lid mount and insert the threaded screws into the holes.
- 14. Screw both parts together, apply low-tear safety adhesive to the screw threads.

